

Zahn Cup

Model No. 2285

This instrument is used for measuring viscosity of gravure printing ink. Etc. The cup is immersed in the subject liquid. On pulling up the cup from the liquid, start the stopwatch to measure the time till liquid is completely discharged the cup.

Select a suitable cup so that the time length may be within 20 to 40 seconds.

Specifications

<Guide for selection of discharge orifice>

Cup	Orifice Diameter	Measurement Range (cSt)
2	2mm	approx. 0 to 70
3	3mm	approx. 20 to 250
4	4mm	approx. 80 to 700
5	5mm	approx. 200 to 1000
6	6mm	approx. 400 to 2000
7	7mm	approx. 900 to 3000

Referential Standard: JIS Z-8803-1991

Outer Dimensions: 40x 40 x 350mm

Instrument Weight: 100g



Sold & serviced by:

OpTest Equipment Inc.

www.optest.com - sales@optest.com - +1-613-632-5169