



# CORRUGATED BOARD Testing Equipment

PAPER TESTING ASSOCIATION

## Stirrer for tissue paper N 4300

### Conform on the standard NF Q 34.020

A sample of toilette paper is agitated in a define water volume. This apparatus measures the time to desintegrate the sample.

- The agitation installation turn at 800 rpm  $\pm$  20 rpm, with polytétrafluoroéthylène rotor
- The rotor is a straight cylinder.

The propeller measures 60  $\pm$  1 mm as diameter and 17  $\pm$  1 mm high with 4 veins in cross.



Sold & serviced by:

***OpTest Equipment Inc.***

*www.optest.com - sales@optest.com - +1-613-632-5169*